


Initial En Route Qualification Training

Handout 00 Aero Center Quick Reference Guide

Course 50148001



Commonly used phraseology which should be committed to memory

DEPARTURES

- WILL THE PILOT OF (Call Sign) ACCEPT A NORTHEAST DEPARTURE WITH TURNS?
- VIA DEPART SOUTHWEST DIRECT SQS AS FILED.
- VIA DEPART NORTHEAST TURN RIGHT/TURN LEFT FLY HEADING (degrees) UNTIL JOINING (victor airway).
- (pilot's requested altitude) IS NOT AVAILABLE.
- CLEARANCE VOID IF NOT OFF BY (clearance void time), IF NOT OFF BY (clearance void time), ADVISE AERO CENTER NOT LATER THAN (time) OF INTENTIONS.
- VERIFY THIS CLEARANCE WILL ALLOW COMPLIANCE WITH LOCAL TRAFFIC PATTERN AND TERRAIN OR OBSTRUCTION AVOIDANCE.
- VISUAL SEPARATION APPROVED BETWEEN (departure call sign) AND (arrival call sign), (departure) RELEASED.
- (second departure call sign) RELEASED (one, two, etc...) MINUTES AFTER (first departure) DEPARTS.

HOLDING

- (call sign) CLEARED TO VKS RADIO BEACON, HOLD SOUTHWEST ON THE ONE NINER FIVE BEARING FROM THE VKS RADIO BEACON, LEFT TURNS, EXPECT FURTHER CLEARANCE (time).
- (call sign) CLEARED TO SQS VORTAC, HOLD SOUTHWEST ON THE TWO FIVE SIX RADIAL, LEFT TURNS, EXPECT FURTHER CLEARANCE (time).
- *(call sign)* CLEARED TO MHZ VORTAC, HOLD NORTHWEST AS PUBLISHED, NO DELAY EXPECTED.
- (call sign) CLEARED TO DINKY INTERSECTION, HOLD NORTHEAST ON VICTOR 18, EXPECT FURTHER CLEARANCE (time).
- BLOCK (altitude) AND BELOW FOR HOLDING AND APPROACH AT SQS.

ARRIVALS

- (call sign) CLEARED VOR RUNWAY FIVE APPROACH CIRCLE TO RUNWAY TWO THREE.
- (call sign) CLEARED APPROACH KVKS AIRPORT.
- (call sign) REPORT CANCELLATION OF IFR THIS FREQUENCY OR WITH AERO CENTER FLIGHT DATA, CHANGE TO ADVISORY FREQUENCY APPROVED.

TIME, SPEED and DISTANCE

Quick Estimate Methods:

Use these methods to convert an aircraft's speed to milesper-minute, or to determine the distance an aircraft will travel in a specified amount of time, or to calculate an estimated time over a fix.

- MPM = Speed (KTS) ÷ 6: Divide the first two digits of an aircraft's speed by 6 to determine its Miles-per-Minute (MPM).
- DT = MPM x TM: Distance Travelled (DT) equals
 Miles-per-Minute (MPM) multiplied by Time in Minutes
 (TM).
- TOF = DT ÷ MPM: Time over a Fix (TOF) equals
 Distance Traveled (DT) divided by Miles-per-Minute (MPM).

INTERPHONE FORMAT

When Initiating a Call, State:

- Who you are calling.
- Who you are.
- Why you are calling.

When Call is Answered, State:

- Where to look.
- Who or what to look for.
- What's happening?

End ALL Calls With Initials

NUMBERS ALLOWED IN GROUP FORM

1. Airline Call Signs:

- AAL552: "American Five Fifty Two,"
- SWA81: "Southwest Eighty One"

2. Aircraft Types:

- C130/A: "C One Thirty slant alpha,"
- MD80/L: "MD Eighty slant lima"
- C172/G: "Cessna One Seventy Two slant golf"

3. Airways:

- **J52:** "J Fifty Two"
- V417: "Victor Four Seventeen"

INBOUNDS

Approach Control

- 1. Call sign
- 2. Type aircraft
- 3. Equipment suffix
- 4. Estimate over fix
- 5. Altitude (Including restrictions with a...)
- 6. Destination if other than JAN/MLU
- 7. **TCP** (Your control...)

VFR Tower

- 1. Call sign
- 2. Type aircraft
- 3. Estimate over fix
- 4. Type of approach (e.g. GWO = "VOR apch")

Arrival Clearance Format

FRAHE

```
• <u>F</u>ix (cleared to...)
```

• <u>R</u>oute (via...)

Altitude

(cross, maintain, etc...)

Holding

(instructions or "as published"...)

• Everything else

(altimeter, frequency, EFC, etc...)